

POWERFLEX®

PART NUMBER

PFR57-211

DESCRIPTION

REAR DROP LINK BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 8 x Polyurethane Bushes
- 8 x Plated Mild Steel Washers
- 4 x Stainless Steel Sleeves
- 1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Unbolt the drop link from the vehicle and roll bar.
2. Press or cut out both rubber bushes.
3. Clean away any remaining rubber from the bore of the link and remove any sharp edges.
4. Push the supplied polyurethane bushes into each side of the link.
5. Apply some of the supplied grease to the bore of each bush.
6. Press a stainless steel sleeve into each bush.
7. Refit the link to the vehicle, placing one of the supplied washers against each bush face.
8. Tension all hardware to manufacturer's recommended torque settings.

