

# POWERFLEX®

## PART NUMBER

# PFR57-533

## DESCRIPTION

### GEARBOX FRONT MOUNTING BUSH INSERT

## INSTALLATION GUIDE

### Contents (parts per pack):

1 x Polyurethane A Bushes

1 x Polyurethane B Bushes

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove the original bolts from the gearbox mount and retain them for refitting.
2. Clean any dirt and corrosion from the mount and file off any sharp edges.
3. Insert the polyurethane A part from the right hand side of the car, ensuring it sits flush with the surface of the mount.
4. Insert the polyurethane B part from the left side of the car, ensuring it sits flush with the surface of the mount. See Fig. 1.
5. Refit the original bolts and tension all hardware to manufacturers recommended torque settings.



Figure 1



Figure 2